



Very Important.

When Required, Waterproof tray must be a fully bonded type & be flashed in to wall reveal at correct depth for tray (dependant on Frame set back) & 150mm above the top of track

Solid Base should be between 100-130mm but NO Greater